

XXS - IFEB20


1 About this manual

This publication provides user information for the installation of the IFEB. The Indoor Fiber Entrance Box is ideal for small to medium size buildings. It provides a flexible fiber management system for transitioning outside plant cable to indoor cable via splicing or with connectorized cable assemblies. It incorporates proven fiber routing procedures, cable termination accessories and splice trays resulting in consistent, high-quality fiber management.

Images in this manual are for reference only and do not always show the actual configuration.

Always refer to the section "5.4 Layout" on page 5 for the actual configuration.


2 Product image



Contents

1	About this manual	1	6.1	Feeder cable preparation	6
2	Product image	1	6.2	Feeder cable installation	6
3	Tools	3	6.3	Route feeder fibers to tray	9
4	Warnings and cautions.....	3	7	Drop cable.....	10
5	IFEB preparation.....	3	7.1	Drop cable installation	10
5.1	Open the box	3	7.2	Route drop fibers to tray	11
5.2	Install trays	4	8	Install 900µm pigtails	12
5.3	Install adapters	4	9	Splicing.....	12
5.4	Layout	5	10	Close the box	13
5.5	Seals	5	11	Disclaimer	13
6	Feeder cable.....	6	12	Contact information	13




3 Tools



From left to right:

- Torx screwdriver
- Phillips screwdriver
- Scissors
- Pliers
- Stripping pliers



4 Warnings and cautions



- Follow the installation instruction steps to ensure the performance of the closure. It is necessary to take precautions and keep the working space clean to protect the closure sealing materials and splices.
- Exposure to laser radiation can seriously damage the retina of the eye. Do not look into the ends of any optical fiber. Do not assume the laser power is turned off or that the fiber is disconnected at the other end. Looking into the ends of any optical fiber is entirely at your own risk. A protective cap or hood **MUST** be immediately placed over any radiating adapter or optical fiber connector to avoid the potential of dangerous amounts of radiation exposure. This practice also prevents dirt particles from entering the connector and adapter.
- Fiber optic cables may be damaged if bent or curved to a radius that is less than the recommended minimum bend radius. Always observe the recommended bend radius limit when installing fiber optic cables and patch cords.




5 IFEB preparation

5.1 Open the box



- 1 Open the box.
- 2 Locate the fiber guidance pens from inside the box cover. These pens can be used to easily & quickly disassemble the seal ports to allow a wrap around cable installation and to handle fibers.





5.2 Install trays




- 1 Install the first tray in position 5 above the patch panel.
- 2 Lower the tray.
- 3 Install the remaining trays, stacking them upwards and place the cover on the top tray.

5.3 Install adapters


Patch panel can be tilted (picture 2) or removed (picture 3) if necessary during installation.



5.4 Layout



5.5 Seals



N°	Description
1	Sealblock 2 x 15mm (feeder cable)
2	Sealblock 16 x 7mm (drop cable)

Note: Important: Install foam to thicken cable to seal the port:

Table 1: Foam length per cable diameter


Sealblock 2 x 15mm	
Cable diameter (mm)	Foam length (±5 mm)
5	170
6	160
7	150
8	140
9	125
10	115
11	105
12	95
13	85
14	70
15	60

6


Feeder cable

6.1

Feeder cable preparation













N°	Description	Preparation
1	Jacket	Remove 1.5 m from the jacket of the cable.
2	Rigid strength member	Cut the strength member to a length of 48 mm.
3	Protection tape	Wrap a piece of protection tape around the cable jacket at a distance of 2 mm from the jacket end.
4	Foam	Cut a piece of foam (length according to Table 1: Foam length). Wrap it around the cable at a distance of 24 mm from the jacket end. At this place the cable will touch the cable seal.









6.2

Feeder cable installation














6.3 Route feeder fibers to tray






7 Drop cable





7.1 Drop cable installation



7.2 Route drop fibers to tray



8 Install 900µm pigtails



9 Splicing

Make splice per local practice and store the splice protector in the splice protector holder. Store the over lengths in loops in the over length storage area.




10 Close the box

 **Note:** Use a blindplate in case of an un-used seal port.

! **Caution:** Ensure all cables are properly positioned inside the box to avoid damaging them when closing the cover.

! **Caution:** Secure all cables to the wall below the box before bending.

Verify that the cover is installed properly with no space between the housing and cover as shown.



11 Disclaimer

All trademarks identified by ® are registered trademarks in the US and may be registered in other countries. All third party product names, trademarks and registered trademarks are property of their respective owners.

This product may be covered by one or more U.S. patents or their foreign equivalents. For patents, see www.cs-pat.com.

This document is not intended to modify or supplement any specifications or warranties relating to CommScope products or services.

12 Contact information

Visit our website or contact your local CommScope representative for more information. www.commscope.com

For technical assistance, customer service, or to report any missing/damaged parts, visit us at:
<http://www.commscope.com/SupportCenter>